

Wall Mount Fiber Optic Box

Signamax Wall Mount Fiber Optic Box is used for the direct termination of fibers. The rear section accommodates cable entry and protects against taking out the cables. Box includes two separate sections for fusion splice trays and for routing optical patch cords to the equipment. Box is fitted with two locks with different keys. The Signamax four-rack space fiber optic enclosure contains all of the features of the two-rack space model, but with additional capacity to manage fiber counts up to 144. Cable entry/exit feature utilizes a flexible grommet seal, which is cut at time of installation to accommodate the desired cable diameters for entry and exit points. These grommets provide a dust & debris barrier during and after installation.




RA2-FO-A05

Wall Mount Fiber Optic Box

PART NO.	DESCRIPTION
RA2-FO-A05	Wall mounted fiber optic box without accessories
RA-FO-24ST	Panel for RA2-FO-A05 and for 24 ST adapters
RA-FO-24SC	Panel for RA2-FO-A05 and for 24 SC adapters
RA-FO-12ST	Panel for RA2-FO-A05 and for 12 ST adapters
RA-FO-12SC	Panel for RA2-FO-A05 and for 12 SC adapters

Colour grey RAL 7035



Panels